



D12 starter bars, at spacings as designed by engineer, drilled into floor slab and bonded with Chemset concrete adhesive 24 hours prior to panel to panel installation

**B3(7)** TYPICAL INTERNAL WALL PANEL / FLOOR SLAB CONNECTION - OPTION 2  
 Scale 1:5