



D12 starter bars, at spacings as designed by engineer, drilled into floor slab and bonded with Chemset concrete adhesive 24 hours prior to panel to panel installation

D3(7) TYPICAL INTERNAL WALL PANEL / FLOOR SLAB CONNECTION - OPTION 2
 Scale 1:5